




HP Pavilion Touchsmart 11z-e000 Hard Drive Replacement

This guide will instruct a user in the replacement of the laptop's hard drive.

Written By: Robert Hemphill



INTRODUCTION

The hard drive for a computer is essentially where all of the computers information is stored. They are crucial to the performance of any computer. Upgrading a hard drive can improve the speed of a computer, as well as allow the user to save more files, run more programs, and generally improve the performance.



TOOLS:

- [Small Phillips Head Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
-

Step 1 — Battery




- Remove battery by pushing the two tabs and pulling the battery outwards slowly but firmly.

Step 2 — Hard Drive




- Wedge your finger (or tool) in between the outer plastic cover of the laptop and the main part of the laptop.
- Pry the outer plastic cover off of the laptop.
- ⓘ Prying the outer plastic cover off may take a significant amount of force.

Step 3




- Unscrew all screws that surround the hard drive with a Philip Head

Step 4



- Carefully lift the hard drive up by holding the tag shown here.

Step 5



- Remove the final attachment to the hard drive located at the end shown here.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-20 01:32:02 PM.